

## Pedal Extension Installation

You will need a Philips #2 screwdriver. Do not over tighten screws during the process.

1. Remove existing pedals (to be used later).
2. Cut and remove zip ties from the pedal extenders.
3. Place half of the existing pedal on the pedal extension piece and snap together.
4. Insert the 1  $\frac{3}{4}$ " screws (supplied) and tighten.  
Note: small flange on the inside of the pedals must be opposite each other.
5. Place assembly on the axle and attach remaining pedal half on the extension assembly and snap together with flanges opposite each other.
6. Insert remaining screws and tighten until snug.

